# **How to Create a Domain Controller**

### Overview

This guide will show you how to enhance your network's security and management capabilities by demonstrating how to promote a Windows Server to a Domain Controller (manually and through a script), then finish by showing you how to tie it to a Windows device (manually and through a script).

## **Prerequisites**

- One Windows server
- One Windows PC


### **Contents**

•	How to Turn Your Windows Server into a Domain Controller	2
•	How to Turn Your Windows Server into a Domain Controller (with PowerShell)	<u>10</u>
•	How to Join a Windows PC to Your Domain	<u>11</u>
•	How to Join a Windows PC to Your Domain (with PowerShell)	14


## How to Turn Your Windows Server into a Domain Controller

Step 1: Log on to the server.


Step 2: Open Server Manager and click the "Add roles and features" button on the right side of the screen.




Step 3: Select Role-based or feature-based Installation.




Step 4: Select the roles in the image below, then press next.




Step 5: Wait for the features to install, then click the option to "Promote this server to a Domain Controller."




Step 6: Next, you will be directed to the Active Directory Domain Services Configuration wizard. Type the name of your domain in the box on the bottom, then press next.



Step 7: Then, specify DNS and GC capabilities by checking the boxes. Afterward, you will be asked to enter your password and press next.




Step 8: Next, you will be taken to the Prerequisites Check section. You might not be able to proceed until you do a bit of troubleshooting. The result below states that I do not have a password under my administrator account.



Step 9: If you had the exact same error:


- a. Go to the Control Panel.
- b. Click Manage Accounts.
- c. Click Change an Account.
- d. Then, click Create Password.


I also had to restart the server for the changes to take place. Afterward, I was able to pass the prerequisite test.



# Step 10. Validate that you can open the installed services.

Below are screen shots of <u>Server and Events</u> and <u>Active Directory Users and Computers</u>.





# How to Turn Your Windows Server into a Domain Controller (with

# **Powershell)**


```
# If you run this script, it will repeat all the actions above

$domainName = Read-Host "Please enter the Domain Name (e.g., example.com)"
$domainNetbiosName = Read-Host "Please enter the Netbios Name (short name for the domain)"

Import-Module ADDSDeployment
Install-ADDSForest
-CreateDnsDelegation:$false
-DatabasePath "C:\Windows\NTDS"
-DomainMode "WinThreshold"
-DomainName $domainName
-DomainNetbiosName $domainNetbiosName
-ForestMode "WinThreshold"
-InstallDns:$true
-LogPath "C:\Windows\NTDS"
-NoRebootOnCompletion:$false
-SysvolPath "C:\Windows\SYSVOL"
-Force:$true
```

## How to Join a Windows PC to Your Domain

Step 1. First, get the IP of your server by opening the Command Prompt, typing ipconfig, then pressing enter.




*Note:* Your server needs to stay turned on for the rest of these steps to work.

Step 2. a. Next, log in to your Windows PC.

- b. Then, open the Control Panel.
- c. Click Network and Internet.
- d. Click Network and Sharing Center.
- e. Click Network Settings.
- f. Then, click on Ethernet0.
- g. Next, right click.
- h. Select Properties.
- i. Click IPV4.


- j. Select Properties again.
- k. Then, type in the IP from Step 1 like so:



Step 3. a. Next, open the Control Panel.

- b. Select System and Security.
- c. Click System.
- d. Click System Properties.
- e. Then, click Change.

f. In the resultant window, add the name of your domain into the box. You will be asked to restart afterword.



Step 4: Open PowerShell, then run the following command to validate whether or not this device has been joined to the domain: ipconfig/all.

```
PS C:\Users\tuffo> ipconfig /all

Windows IP Configuration

Host Name . . . . . . . : DESKTOP-I6U54J2

Primary Dns Suffix . . . . : ttufford.local

Node Type . . . . . : Hybrid

IP Routing Enabled . . . . : No

WINS Proxy Enabled . . . . : No

DNS Suffix Search List . . . : ttufford.local

localdomain
```

# **How to Join a Windows PC to Your Domain (with PowerShell)**

```
# If you run this script, it will repeat all the actions in the previous section

$yourDomain = Read-Host "Please enter your domain name: "
$yourUsername = Read-Host "Please enter your username: "
$yourPassword = Read-Host "Please enter your password: "

$domain = $yourDomain
$username = "$yourDomain\$yourUsername"
$password = $yourPassword
$credential = New-Object System.Management.Automation.PSCredential($username, (ConvertTo-SecureString $password -AsPlainText -Force))
Add-Computer -DomainName $domain -Credential $credential -Restart
```